

100
HOME GATEWAY/
CONTROLLER

— 104 bus / first communication medium

FIRST DEVICE / 102
CONSUMER
ELECTRONICS DEVICE

Fig. 1

09770046 030204

FIG. 2




Fig. 2

0979046-020704




Fig. 3